

Automower

SOLAR HYBRID

2008

Spare parts

Ersatzteile

Pièces détachées

Reserve onderdelen


Repuestos

Reservdelar


| PART NUMBER | SQUARE | NOTE | PART NUMBER | SQUARE | NOTE | PART NUMBER | SQUARE | NOTE |
|--------------|--------|------|--------------|--------|------|--------------|--------|------|
| 115 09 66-XX | J | | 535 07 59-01 | E | | 535 13 59-01 | B | |
| 115 09 67-XX | J | | 535 07 60-01 | BE | | 535 13 72-02 | D | |
| 115 09 68-XX | J | | 535 07 60-02 | BC | | 535 13 73-01 | B | |
| 115 09 69-XX | J | | 535 08 09-01 | B | | 535 13 79-02 | F | |
| 115 09 80-XX | J | | 535 08 15-01 | E | | 535 13 81-01 | D | |
| 115 09 81-XX | J | | 535 08 25-01 | E | | 535 13 84-05 | C | N |
| 115 09 82-XX | J | | 535 08 76-01 | D | | 535 13 85-01 | E | |
| 501 00 18-01 | I | | 535 08 78-01 | D | | 535 13 87-01 | I | |
| 501 00 37-02 | D | | 535 08 89-01 | H | | 535 13 87-02 | I | |
| 501 00 42-01 | D | | 535 08 98-01 | B | | 535 13 88-01 | I | |
| 501 98 02-01 | H | | 535 09 12-01 | D | | 535 13 88-02 | I | |
| 501 98 02-02 | H | | 535 09 14-01 | C | | 535 13 92-01 | D | |
| 501 98 03-01 | H | | 535 10 17-01 | C | | 535 13 94-01 | D | |
| 501 98 03-02 | H | | 535 12 09-01 | D | | 535 13 96-01 | D | |
| 502 23 91-01 | E | | 535 12 20-01 | D | | 535 14 00-02 | F | |
| 502 85 96-01 | AD | | 535 12 21-02 | D | | 535 14 05-01 | B | |
| 504 04 97-01 | H | | 535 12 22-01 | C | | 535 14 12-01 | I | |
| 504 05 37-01 | F | | 535 12 23-01 | E | | 535 14 12-02 | I | |
| 504 20 08-01 | D | | 535 12 24-01 | D | | 535 14 27-06 | I | |
| 504 62 68-01 | A | | 535 12 25-01 | C | | 535 14 32-01 | C | |
| 504 62 70-01 | A | | 535 12 25-01 | C | | 535 14 47-01 | C | |
| 504 62 71-01 | A | | 535 12 31-01 | D | | 540 06 03-03 | C | |
| 504 62 72-01 | A | | 535 12 36-01 | E | | 544 01 13-01 | C | |
| 504 62 73-01 | B | | 535 12 37-01 | G | | 544 12 69-01 | C | |
| 504 62 74-01 | B | | 535 12 37-02 | G | | 544 14 15-01 | C | |
| 504 70 34-02 | AB | | 535 12 37-03 | G | | 544 17 75-01 | H | |
| 504 72 31-01 | B | | 535 12 37-04 | G | | 544 21 73-03 | B | |
| 504 82 13-01 | I | | 535 12 37-05 | G | | 544 41 00-01 | D | |
| 504 87 76-01 | A | | 535 12 39-01 | C | | 544 45 41-01 | F | |
| 504 87 77-01 | B | | 535 12 43-03 | F | | 544 87 09-04 | B | |
| 504 87 78-01 | B | | 535 12 44-01 | F | | 544 89 98-02 | C | |
| 505 12 78-01 | I | | 535 12 45-02 | B | | 544 90 51-02 | D | |
| 505 12 78-02 | I | | 535 12 47-02 | F | | 544 90 58-02 | D | |
| 505 13 14-01 | B | | 535 12 50-01 | E | | 544 90 68-02 | D | |
| 505 13 27-01 | I | | 535 12 52-01 | D | | 544 90 71-01 | B | |
| 505 13 28-01 | I | | 535 12 56-01 | D | | 544 90 78-01 | D | |
| 505 15 40-01 | A | | 535 12 63-01 | E | | 544 98 07-01 | G | |
| 505 16 15-01 | B | | 535 12 64-01 | E | | 544 98 07-02 | G | |
| 505 16 16-01 | A | | 535 12 73-05 | H | | 544 98 07-03 | G | |
| 505 17 43-01 | C | | 535 12 79-01 | BC | | 544 98 07-04 | G | |
| 505 34 77-02 | F | | 535 12 85-01 | F | | 544 98 07-05 | G | |
| 505 45 07-01 | A | | 535 12 86-01 | F | | 544 98 38-04 | F | |
| 505 45 78-01 | A | | 535 12 87-02 | F | | 725 53 66-05 | B | |
| 505 45 79-01 | C | | 535 12 90-01 | H | | 728 82 85-01 | E | |
| 505 69 99-91 | I | | 535 12 93-02 | B | | 732 21 16-01 | AB | |
| 506 49 40-01 | C | | 535 13 03-08 | B | | 734 11 37-41 | BE | |
| 506 49 43-03 | D | | 535 13 03-10 | ABCDEF | | 734 11 45-71 | D | |
| 506 49 53-01 | C | | 535 13 03-12 | AB | | 735 58 35-09 | D | |
| 506 60 71-01 | B | | 535 13 03-14 | BCDF | | 738 22 95-55 | D | |
| 510 09 67-03 | B | N | 535 13 03-16 | D | | | | |
| 510 16 66-01 | A | | 535 13 04-01 | B | | | | |
| 513 99 61-00 | B | | 535 13 05-01 | E | | | | |
| 514 96 79-00 | B | | 535 13 16-01 | H | | | | |
| 535 07 55-01 | E | | 535 13 23-02 | I | | | | |
| 535 07 57-02 | E | | 535 13 29-01 | D | | | | |

N = New part, Neues teil, Nouvelle piece, Nueva pieza, Ny detalj


A compl 504 62 68-01




B




C




D




E







- G** compl 544 98 07-01 (EU)
 compl 544 98 07-02 (UK)
 compl 544 98 07-03 (CH)
 compl 544 98 07-04 (US)
 compl 544 98 07-05 (AU/NZ)





H





**Accessories
Zubehöre
Accessoires
Accesorios
Tillbehör**


 535 13 87-01 (9 pcs Original)


 535 13 87-02 (9 pcs)

 535 13 88-01 (30 pcs Original)


 535 13 88-02 (30 pcs)

 505 12 78-01 (500 pcs Original)

 505 12 78-02 (500 pcs)



501 00 18-01
Loop wire interruption tester




535 14 12-01 (85 ml)


535 14 12-02 (300 ml)




535 14 27-06 **CD Autocheck 2008**



535 13 23-02 **Automower-PC Cable (USB)**




504 82 13-01



505 13 27-01

505 13 28-01



505 69 99-91

J



| | | |
|--|--------------|-------------|
| Quick Guide 220 AC & 230 ACX | 115 09 69-XX | (US is -26) |
| Quick Guide 210 C | 115 09 68-XX | (US is -26) |
| Quick Guide Solar Hybrid | 115 09 82-XX | (US is -26) |
| Owner's Manual 220 AC & 230 ACX | 115 09 67-XX | |
| Owner's Manual 210 C | 115 09 66-XX | |
| Owner's Manual Solar Hybrid | 115 09 81-XX | |
| Technical Handbook 2008 | 115 09 80-XX | |

| | |
|-----|------------|
| -01 | Svenska |
| -06 | Dansk |
| -11 | Soumi |
| -21 | Norsk |
| -26 | GB English |
| -31 | Français |
| -36 | Nederlands |
| -41 | Italiano |
| -46 | Español |
| -51 | Deutsch |
| -56 | Русский |
| -59 | Português |
| -61 | Polski |
| -63 | Eesti |
| -64 | Latviski |
| -65 | Lietuvių |
| -68 | Slovák |
| -84 | Slovenčina |
| -90 | Česky |
| -95 | US English |